


# TRIPLE SYSTEMS

## 4-Wheel Drive Tractors With Planetary Drive Complete Systems



This system is a complete kit consisting of twelve wheels. Kit is used when changing tire size or replacing a current dual system to the heavy duty Tiger Cat-style triple system.

### Kit Includes:

- (4) Prime wheels
- (4) Dual wheels
- (4) Triple wheels
- (4) Bolt kits to bolt the dual wheel to the prime wheel
- (4) Bolt kits to bolt the triple wheel to the dual wheel

Tire Size	Wheel Size	Prime Wheel Inside Meas.	Space Between Tires	Wt. in lbs.
18.4 - 38 18.4R38	16 x 38	13"	9"	4,172
20.8 - 38 20.8R38	18 x 38	13"	7"	4,412
18.4 - 42 18.4R42	16 x 42	13"	9"	5,232
20.8 - 42 20.8R42	18 x 42	13"	7"	5,472
18.4R46	16 x 46	12"	9"	5,706
620/70R42	20 x 42	12"	7"	5,684

All measurements on the above chart are approximate.

### Bolt Pattern Verification

Tractor Make	# of Bolts	Bolt Circle Diameter	Bolt Hole Size	Pilot Hole Size
Case IH/Stieger	10	20-1/8"	15/16"	17-7/8"
	20	20-1/8"	15/16"	17-7/8"
Ford/Versatile	16	25-11/16"	15/16"	23-7/8"

When ordering triple systems for this page, please specify the following information:

- Verify the tractor bolt pattern
- Tractor make and model
- Paint color